

Specifications for building a patio from sand set interlocking concrete ✂ brick pavers

Remove grass sod to a depth of 6" below final patio grade.

Instal 3 1/2" of crushed concrete screening material.

Using a pate compacter compact the screening material in place.

Slope and grade the compacted base to provide for water runoff.

Lay 2 3/8" interlocking concrete brick pavers over compacted base.

Instal a tapered concrete border (edge restraint) at all exposed edges.

Spread a thin layer of fine sand over the pavers.

Tamp pavers to final grade and sweep sand into joints to lock pavers.

Hose off remaining sand.